

SHOWER TEST KIT

To facilitate easy weekly testing of shower equipment, as required by the ANSI Z 358.1-2014 standard, Spill Station recommends the use of a Shower Test Kit.

Water from the shower nozzle is directed into a container via the funnel, allowing maintenance personnel to measure the delivery of water whilst ensuring they and the floors are kept dry.

The Shower Test Kit includes a white 10L bucket to contain the water during testing, also allowing for water flow rates to be calculated by measuring the time taken for the bucket to be filled.

Please contact our team for more information.

SPECIFICATIONS		
FUNNEL		600GSM PVC coated Fabric
FUNNEL SUPPORT COLLAR		PVC Pipe
TELESCOPIC HANDLE		PVC pipe
10 LITRE CONTAINER		Plastic bucket Marked at 10L
DIMENSIONS		
Item Code	FUNNEL	1980mm long 360mm diameter upper opening 180mm diameter lower opening
H-STK		
	10 LITRE CONTAINER	280mm high 260mm diameter



SHOWER MODESTY CURTAIN

Optional Fittings

Offers privacy to a casualty in situations where items of clothing must be removed. The curtain also prevents water and contaminants from splashing the immediate area around the safety shower.

The opaque PU coated nylon curtain is attached to a circular shaped stainless steel rail to ensure the user is completely concealed for maximum privacy.

SPECIFICATIONS		
MATERIALS OF CONSTRUCTION		
CURTAIN RAIL & MOUNTING BRACKETS		Stainless Steel
CURTAIN		PU nylon
DIMENSIONS		
Item Code	DIAMETERxDROP	4m (13ft) x 2m (6.5ft)
H-CR		
H-WPCR		



WALL MOUNTED/PEDESTAL MOUNTED STAINLESS STEEL 304 EYE/FACE WASH

ECONOMY RANGE

Item Code	Description
H-D5020	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH WITH POLY SIGN

Open stainless steel bowl, wall-mounted emergency eye/face wash featuring twin spray nozzles protected by dust covers which lift off upon activation via the push plate. The Inbuilt flow regulator valve guarantees an optimum water flow. The eye wash diffusers are fitted with fine mesh strainers designed to give a gentle flow of aerated water at 12 litres per minute as per the ANSI standard.

This unit is intended for indoor use but can be located outdoors where there is no risk of overheating.

SPECIFICATIONS	
OPERATING PRESSURE	2.0 to 6 BAR G (29 to 87 PSI)
TEST PRESSURE	10.3 BAR G (149 PSI)
MINIMUM FLOW AT OPERATING PRESSURE	Shower: 76 litres/minute minimum (20 US Gallons). Eye/face wash: 12 litres/minute minimum (3 US Gallons)
MINIMUM AMBIENT OPERATING TEMPERATURE	5° C (41° F)
MAXIMUM AMBIENT OPERATING TEMPERATURE	35° C (95° F)

PEDESTAL MOUNTING OPTIONS AVAILABLE	
Item Code	Description
H-D5020CP	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH COMPLETE WITH PP SIGN AND SS 304 PEDESTAL
H-D5020CPG	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH COMPLETE WITH PP SIGN AND GRP PEDESTAL
H-DA003	GRP RED FOOT CONTROL PANEL ASSEMBLY FOR EYE/FACE WASH ACTIVATION SUITS H-D5016, H-D5017 & H-D5020

