

# 348 Sani-Master™

## Ergonomic, Anti-fatigue & Safety Matting - Hygiene Matting

This 19-mm thick extendable mat cleans, sanitizes and dries shoes, recommended to be placed at entrances to prevent contamination. As traffic passes, rubber tips bend to immerse soles in disinfectant solution, absorbing mat section cleans and dries shoes to prevent slips.

### **Brand Notrax®**

**Category:** Hygiene Matting

**Product Number:** 348

**Product Family:** Industrial & Commercial Matting

**Product Group Ergonomic:** Anti-fatigue & Safety Matting

**Product Name:** Sani-Master™

**Recommended use:** At doorways, starter rooms, packaging areas, laboratories, employee locker rooms, break rooms, refuse areas and receiving areas. Any place where spread of contamination needs to be limited.

**Type:** Wet Areas - Hygienic Mats

**Usage Intensity:** Heavy duty

### TECHNICAL SPECIFICATIONS

- **Application:** Industrial Environments
- **Edges:** Bevelled rubber borders on all four sides
- **Material:** Natural rubber
- **Material Group:** Natural rubber
- **Process:** Compression Moulding
- Convenient mat size fits most doorways
- Extendable sections for a longer drying zone for wet sanitized shoe soles
- 100% tough natural rubber compound; designed to resist most chemicals and variations in temperature
- Heavy duty

### COLOURS

Charcoal/Black

### INDOOR/OUTDOOR - DISINFECTION ENTRANCE MATTING

### ART 348SANI-MASTER™ (REGULAR)

### SPECIFICATIONS

Item Code	Dimensions	Weight kg
<b>348S0033CH</b>	91.4cm x 105cm (2-Zones)	10.7 kg
<b>348S0035CH</b>	91.4cm x 152.5cm (3-Zones)	15.5 kg
<b>348S0037CH</b>	91.4cm x 200cm (4-Zones)	20.4 kg

### REQUEST CHEMICAL FOR DISINFECTING

