

# SHOWER TEST KIT

To facilitate easy weekly testing of shower equipment, as required by the ANSI Z 358.1-2014 standard, Spill Station recommends the use of a Shower Test Kit.

Water from the shower nozzle is directed into a container via the funnel, allowing maintenance personnel to measure the delivery of water whilst ensuring they and the floors are kept dry.

The Shower Test Kit includes a white 10L bucket to contain the water during testing, also allowing for water flow rates to be calculated by measuring the time taken for the bucket to be filled.

Please contact our team for more information.

## SPECIFICATIONS

<b>FUNNEL</b>	600GSM PVC coated Fabric
<b>FUNNEL SUPPORT COLLAR</b>	PVC Pipe
<b>TELESCOPIC HANDLE</b>	PVC pipe
<b>10 LITRE CONTAINER</b>	Plastic bucket Marked at 10L

## DIMENSIONS

Item Code		
	FUNNEL	1980mm long 360mm diameter upper opening 180mm diameter lower opening
	10 LITRE CONTAINER	280mm high 260mm diameter

